

Matrix RGBW Modes Quick Reference Guide

Double click the “LOCK / MENU” button to change modes

CCT

CCT 5600K

INT	GN +	LOCAL
92	0.12	

LOCK / MENU

CCT/HUE GN/SAT INT

CH	DMX Control
1	Intensity
2	CCT
3	GN (±Green)

HSI

HUE 140°

INT	SAT	LOCAL
92	76	

LOCK / MENU

CCT/HUE GN/SAT INT

CH	DMX Control
1	Intensity
2	Hue (360° Color)
3	Saturation

RGBW

DMX CONTROL ONLY
CONNECT DMX

LOCK / MENU

CCT/HUE GN/SAT INT

CH	DMX Control	CH	DMX Control
1	Intensity	4	Blue
2	Red	5	White
3	Green		

EFFECT

Cop Car < LOCAL >

COLOR	FLASH	INT
BRW	Double	89

LOCK / MENU

CCT/HUE GN/SAT INT

Candle

Lightning

Cop Car

Strobe

Club Light

Color Chase

Fireworks

- 7 lighting effects and 5 savable presets.
- Change the intensity, frequency, and other custom settings for each effect.

GEL

Blue Green < LOCAL >

HUE	SAT	INT
172°	78%	41%

6500k

LOCK / MENU

CCT/HUE GN/SAT INT

	Bastard Amber		Light Red		No Color Blue
	Straw		No Color Pink		Daylight Blue
	Light Amber		Middle Rose		Primary Blue
	Light Flame		Light Rose Purple		Moss Green
	Golden Amber		Suprise Pink		Blue Green

- 15 popular gels and 5 savable presets
- Choose between **tungsten** or **daylight**.
- Make easy adjustments with intensity, hue, and saturation control.

CCT + HSI

DMX CONTROL ONLY
CONNECT DMX

LOCK / MENU

CCT/HUE GN/SAT INT

CH	DMX Control	CH	DMX Control
1	Master Intensity	4	Hue Intensity
2	CCT	5	Hue (360° Color)
3	GN (±Green)	6	Saturation

CCT + RGBW

DMX CONTROL ONLY
CONNECT DMX

LOCK / MENU

CCT/HUE GN/SAT INT

CH	DMX Control	CH	DMX Control
1	Master Intensity	5	Red
2	CCT	6	Green
3	GN (±Green)	7	Blue
4	Hue	8	White